VIBRATION: MIL-STD-202, METHOD 204, COND. B SHOCK: MIL-STD-202, METHOD 213, COND. I THERMAL SHOCK: MIL-STD-202, METHOD 107, COND. B CORROSION: MIL-STD-202, METHOD 101, COND. B MOISTURE RESISTANCE: MIL-STD-202, METHOD 106

MATERIALS

BODY: STAINLESS STEEL PER SAE-AMS-QQ-S-763 FERRULE: ANNEALED. BRASS PER ASTM B16 OR COPPER PER ASTM B124

CENTER CONTACT: BERYLLIUM COPPER PER ASTM B196 DIELECTRIC: TEFLON PER ASTM D1710 GASKET: SILICON RUBBER PER ZZ-R-765

FINISHES

BODY: PASSIVATEO

FERRULE: BRIGHT NICKEL PER QQ-N-290 CENTER CONTACT: GOLD PER MIL-G-45204 3

DWG NO. CSS722-I

REVISIONS


D

В

Α

ECN ZONE REV. DESCRIPTION DATE APPROVED 12898 N/C NEW RELEASE 9/14/01 CAC A REVISE PICTORIAL OF CONN, DIM WAS 1.067 85 X 1. BEGIN BY CUTTING THE CABLE OFF SQUARE.

2. WHEN USING AUTOMATIC STRIPPING EQUIPMENT, STRIP CABLE AS SHOWN STARTING WITH L1 AND ENDING WITH L3. TAKE CARE NOT TO NICK THE CONDUCTORS WHILE STRIPPING THE DIELECTRIC AND JACKET. IF AUTOMATIC STRIPPING EQUIPMENT IS NOT AVAILABLE, STRIP ONLY L1 AND L3 AND TRIM EXCESS BRAID AT STEP 10.



3. SLIDE THE FERRULE AND ADHESIVE SHRINK TUBING OVER THE END OF THE CABLE



4. SOLDER THE CONTACT ONTO THE CENTER CONDUCTOR, PER MIL-STD-2000, USING 63Sn/37Pb SOLDER OR CRIMP WITH M22520/5-11 DIE (B HEX), ENSURE THE CONTACT IS BUTTED AGAINST CABLE DIELECTRIC, CLEAN ALL FLUX RESIDUES USING AN APPROPRIATE FLUX CLEANER.




5. USING TWEEZERS, FOLD THE OUTER BRAID BACK OVER THE CABLE JACKET, LEAVING AS MUCH WEAVE AS POSSIBLE.




6. SLICE THE ALUMINUM/POLYESTER FOIL LENGTHWISE ABOUT EVERY 1/8". GENTLY ROTATE PIN TO SEPARATE THE FLAT FOIL BRAID AND ALUMINUM/POLYESTER FOIL FROM THE DIELECTRIC. USING TWEEZERS, FOLD BACK ALUMINUM/POLYESTER FOIL OVER THE OUTER BRAID.



7. USING TWEEZERS, FOLD THE INNER BRAID BACK OVER THE OTHER SHIELDS, LEAVING AS MUCH WEAVE AS POSSIBLE. NOTE: DO NOT UNRAVEL DIELECTRIC WHEN PULLING BACK INNER SHIFLD.



8. SLIDE THE BODY OF THE CONNECTOR OVER THE END OF THE CABLE UNTIL THE NOTCH IN THE CONTACT SEATS WITH THE DIELECTRIC RIDGE INSIDE THE CONNECTOR BODY.



9. FOLD ALL THREE BRAIDS UP OVER THE NECK OF THE CONNECTOR BODY.



10. SLIDE THE FERRULE UP OVER THE SHIELDS AND AGAINST THE CONNECTOR BODY. TRIM AWAY ANY EXCESS BRAID. CRIMP THE FERRULE ONCE. NEXT TO THE BODY, USING THE M22520/5-11 DIE (A HEX) IN A M22520/5-01 TOOL FRAME, APPLY ADHESIVE HEAT SHRINK.



NOTES

1. ALL DIMENSIONS ARE IN INCHES.

ENSURE HEAT SHRINK IS INSTALLED PRIOR TO CRIMPING CONNECTOR.

ADHESIVE HEAT SHRINK SHOULD BE APPLIED IN ACCORDANCE WITH ECS WORK INSTRUCTION WIDO7. CONTACT ECS FOR A COPY OF THIS WORK INSTRUCTION.

CONNECTOR DIMENSIONS ARE FOR REFERENCE ONLY.

5. PICTORIALS SHOW CONNECTOR INSTALLATION ON ECS 311901 CABLE. WHEN INSTALLING THIS CONNECTOR ON 3C142B OR 3C058A THERE ARE ONLY ONLY 2 BRAID SHIELDS WHICH SHOULD BE FOLDED BACK AS SHOWN IN STEP 5 AND STEP 6 WOULD BE OMITTED.

ALL LENGTHS IN INCHES		ELECTRONIC CABLE SPECIALISTS FRANKLIN, WI 53132 PHONE: (414) 421-5300					
APPROVALS	DATE					• •	
DRAWN BY:	_	TITLE	CH	STOME	P 9	DECIFIC	∧TI∩N
E FOSSELL	07/26/01	"" CUSTOMER SPECIFICATION					
CHECKED BY:	KED BY: SMA STRAIGHT PLUG FOR ECS CABLE						S CABLE
	1	3C142B, 311901, 3C058A					
DESIGNED BY:		· · · · · · · · · · · · · · · · · · ·					
		SIZE	CAGE	CODE	LEVEL	PART NO.	
PROJECT ENG:		В	3 66197		IC.	CSS722	
ENG. MGR.				ı			
D KNOLL	9/19/01	SCALE:		FILE NO. F:\E\SPEC\CONN\INST\CSS922			SHEET OF